



The Powdermaster blower attachment is supplied as a kit that can easily be fitted to the Powdermaster applicator. This is particularly valuable where gravity feed is not possible or difficult to accommodate.

A wiring loom is included that enables the electrical connections to be made via a switching control circuit to synchronise the operation of the blower with the Powdermaster.


The blower assembly can be mounting so that the pipe outlet is in a left or right direction. It can be fitted to both 50kg or 80kg Powdermaster, with digital and non digital controller.

Below are some images showing how the Powdermaster with bower attachment blower attachment has been mounted on some machines.

Baler mounted



TECHNICAL DATA	
Supply Voltage	12V/DC (10.6V DC to 16.4V/DC)
Current consumption	11.5A
Fuse rating	15A
	<i>The fan power supply is independent of the applicator. The fan does not draw power from the applicator.</i>



WARRANTY

Provided installation is carried according to these instructions a warranty of 1 year from date of delivery applies. This covers faulty manufacture only and does not cover wear and tear through normal use or mechanical or chemical damage that has occurred to parts through misuse or unauthorised attempts to repair the unit. In the case of faulty manufacture, claims are limited to repair of the unit and its return to the customer.