



Pump mounting bracket assembly parts list



ITEM NO	DESCRIPTION	QTY
1	MOTOR/PUMP MOUNTING BRACKET	1
2	MOTOR PUMP ASSEMBLY	1
3	1/4IN BSP MALE - 1/4IN HOSE TAIL	1
4	1/4IN BSP FEMALE TO 1/4 IN HOSE TAIL	1
5	ROUND SLEEVED GROMMET	1
6	ROUND CABLE GROMMET	2
7	ROUND GROMMET	2
8	M5 SS HANKBUSH	2
9	M6 PLN WASHER	2
10	M6X12MM POSI SCREW	2
11	M5 PLN WASHER	2
12	M5X10 POSI SCREW	2
13	M5 PLN WASHER	5
14	M4 X 10 SS SCREW	4
15	NYLON 6.6 P CLIP 6.4mm DIAM	1
16	M4 FULL NUT	1
17	INLET TUBE 340MM	1
18	OUTLET TUBE 230MM	1
19	3 POLE XLR PLUG AND LEAD	1

ULV motor/pump assembly parts list



ITEM NO	DESCRIPTION	QTY
1	MOTOR AND SENSOR ASSEMBLY	1
2	MOTOR TO PUMP MOUNTING BUSH	1
3	PUMP ROTOR	1
4	ROTATION LABEL	1
5	M5X25mm SS COUNTER SUNK SCREW	2
6	NO.8X12mm POZI HEAD SELF TAP SCREW	4
7	M4 X 8 SS SLOT SCREW	3
8	PUMP HEAD BACK PLATE	1
9	TUBE SET MOUNT	1
10	TUBE SET	1
11	PUMP HOUSING	1
12	M4X6MM GRUB SCREW	1
13	ROTOR SLIP WASHER (not allways fitted)	1